MERCATOR ikuü

Marely Security Camera (Wi-Fi®)
SSC010

Features
- Wi-Fi® (No hub required)
- Freestanding or wall/ceiling mountable
- Detects motion/sound (with notification option)
- Pan and tilt function with motion tracking
- 1-way or 2-way audio
- Infrared night vision
- Built-in Siren, Adjustable Volume and Duration
- Adjustable Activity area, and human filter
- 5V USB adapter & cable supplied
- Streaming available 24/7 on demand via the app
- Rolling storage - no need to maintain SD card's storage capacity
- 3-year warranty

Network/Device Requirements

| Connectivity	Wi-Fi®
Requirements	Existing 2.4GHz Wi-Fi® network
Protocol	IEEE 802.11 b/g/n
Wireless Frequency	2.4GHz
App Requirements	Mobile device running iOS or Android. (Refer to ikuu.com.au for minimum specs)

Technical Specifications

Supply Voltage	5V DC (adapter supplied)
Power Consumption	5W
IP Rating	IP20 (indoor use only)
Colour	White
Housing Material	Polycarbonate & ABS
Weight	180g
Dimensions (H x Diam)	117mm x 75mm
Power Port	Micro USB
Power Cable (supplied)	Type-A to Micro USB (male-male)
Detection Distance	up to 8m [1]
Pan & Tilt Range	Horizontal: 350°, Vertical: 80°
Field of View	100°
Video Resolution	1296p HD
Supported Memory (16GB supplied)	Requires class 10 micro-SD card (max 256GB)
Audio	1-way or 2-way audio
Night Vision	IR, up to 10m vision [1]
Recording Method	Continuous or event recording

[1] Varies depending on the mounting location and temperature

Included Accessories
Micro USB charging cable, USB power adaptor, Mounting bracket, Mounting screws, Wall plugs.

Camera Field of View 100°
Motion Detection Range up to 5m
2.4m Mounting Height (ceiling height)

*Download the app using the QR code or visit the iOS or Google Play store.

www.ikuu.com.au

Mounting Instructions

Before choosing prefered location, check Wi-Fi strength/coverage is adequate.

CEILING MOUNT

1. Using the mounting bracket as a template, mark the screw positions on the ceiling.
2. Drill holes into the ceiling and push the wall plugs into the holes.
3. Use the mounting screws to install the mounting bracket to the ceiling.
4. Attach the camera to the mounting bracket and tighten the knob screw to secure the camera.

NOTE: To get the correct orientation for ceiling mount, navigate to settings > basic function settings > flip screen.

*Download the app using the QR code or visit the iOS or Google Play store.

www.ikuu.com.au